

CLIMATIX™
CLIMATIX IC20
User manual

6 Controller IP settings


Different IT infrastructures and variations exist in the field when connecting the Climatix controller via internet to Climatix IC. Climatix controllers do not require a fixed IP address and users do not even deal with IP addresses. And yet certain settings may be requested or require verification for proper Internet connectivity (depending on the local infrastructure).

6.1 DHCP active

No further settings required when the IP setting is set to DHCP active. This is also the most common (and recommended) configuration.

6.2 Fixed IP

Certain installations request fixed IP numbers. A DNS server address needs to be entered in this case.



0x001D	ActualMask[z]	0	WORD
0x001E	ActualGate	0	ULONG
0x001F	ActualGateway[w]	0	WORD
0x0020	ActualGateway[x]	0	WORD
0x0021	ActualGateway[y]	0	WORD
0x0022	ActualGateway[z]	0	WORD
→ 0x0023	Web:UserName	ADMIN	STR16
→ 0x0024	Web:Password	SBTAdmin!	STR16
→ 0x0025	FTP:UserName	ADMIN	STR16
→ 0x0026	FTP:Password	SBTAdmin!	STR16
→ 0x0027	JSON:UserName	JSON	STR16
→ 0x0028	JSON:Password	SBTAdmin!	STR16
→ 0x0029	Admin:UserName	ADMIN	STR16
→ 0x002A	Admin:Password	SBTAdmin!	STR16
→ 0x002B	JSON:Language	16384	WORD
→ 0x002C	Climatic:Enable	Active (1)	BOOL
→ 0x002D	Climatic:Port	4242	WORD
→ 0x002E	Climatic:Auth		STR16
→ 0x002F	HTTP:Enable	Active (1)	BOOL
→ 0x0030	HTTP:Port	80	WORD
→ 0x0031	TFTP:Enable	Active (1)	BOOL
→ 0x0032	TFTP:Port	69	WORD
→ 0x0033	FTP:Enable	Active (1)	BOOL
→ 0x0034	FTP:Port	21	WORD
→ 0x0035	IP	192.168.1.199	STR16
→ 0x0036	SubnetMask	255.255.255.0	STR16
→ 0x0037	Gateway	0.0.0.0	STR16
→ 0x0038	PrimaryDNS	0.0.0.0	STR16
→ 0x0039	SecondaryDNS	0.0.0.0	STR16

6.3 Proxy server environment

Climatix controllers do **not** support proxy server environment, primarily due to the complexity of set up and a lack of authority by the IT department.

Separate Internet connectivity (3G/4G modem) may be required to access this type of unit.

6.4 Troubleshooting

Even all settings might have been correct entered, due to complexity and habit of switches, routers or DNS servers, the below hints will help to establish the connectivity:

IP Settings (aoIP)	0x0003 Link detected (no)	Ethernet cable not plugged in
	0x0035 IP Address	Must be from the local network
	0x0038, 0x0039 DNS	At least 0x0036 must have a valid DNS server address (e.g. 8.8.8.8)
	0x0036 Subnet Mask	Must match the network configuration
	0x0037 Gateway	Must contain a router IP address
Cloud settings (aoCSL)	0x0000	Server IP must be correct (https://www.connectivity.ccl-siemens.com)
	0x0004	Check if connection is enabled (1 or 2)
	0x0006	The distributor must contain the value from the Tenant
IP connectivity	Connect PC to the same network as the Climatix controller. Check out the general Internet access (port 80 open). Compare the PC settings with controller's	
Others	Connect SCOPE tool to Climatix controller and read out its diagnostic file to check, if there is something stated (missing CSL mapping, link detected)	

7 Site activation

The controller (site) can be connected to Internet Climatic IC (using the inbuilt IP port) and activated as soon a Climatic controller is prepared and preloaded with a valid CSL mapping file.

The chapter below describes and illustrates the workflow and provides tips on additional required settings

7.1 Connect ethernet cable

Plug in the ethernet cable to the Climatic controller IP port (T-IP) , as pictured below.



7.2 Climatic IC login

The user opens the web browser and enters the following URL: www.climaticix.com to activate the new Climatic controller.



The user is requested to enter his username and password.

Note

The "Sign up" function is not enabled for Climatic controllers.

7.2.1 Reset password

A reset password function is available in the event of a lost or forgotten password. The user enters his or her email address to receive a temporary password (which must then be changed).

Reset your password

Email address